


**EXTRA DEEP TANK INSTALLATION INSTRUCTIONS**

**USE ONLY (PEA STONE) AS BACKFILL MATERIAL.**

It must NOT contain contaminants of any kind such as sticks, rocks, lumps, mud, etc. Tanks are to be lowered into the excavation using the lifting hooks on the tank. Tanks must NOT be buried deeper than the tank label indicates, measuring from the top of the tank to the finished ground level.

Carefully lower tank onto compacted 305mm (12") bed. Level tank, this is critical for proper operation. Fill tank with no more than 610mm (24") of water above the height of backfill material. Backfill around tank in uniform 305mm (12") lifts, ensuring a firm envelope around the tank. The quality of the envelope is critical to ensure long-term performance. Connect inlet and outlet piping with flexible connections to compensate for ground movement. Continue backfilling in 305mm (12") lifts until you reach the desired level. It is recommended that the desired elevation at the manhole extension be

 <b>Concrete &amp; Fiberglass Products Ltd.</b> 712 KERRISDALE RD. VANDERBILT BEACH, NB ROC 2G2 PH (504) 389-6651 FAX (504) 389-6650 EMAIL: INFO@DLPRODUCTS.CA WEBSITE: WWW.DLPRODUCTS.CA		
EXTRA DEEP BURIAL INSTRUCTION	DATE: _____	DRAWN BY: AZ
	SCALE: _____	PAGE: -- OF --